


Motorized Desktop Socket




Manual

Read the instruction carefully and save the instructions for future reference before starting the installation.

Product Installation:


1.Hole Opening: Opening a hole in $\phi 100\text{mm}$




2.Remove the equipment and withdraw the thread fastener left-handed



3.Inset the equipment into the open hole



4.Fasten the right-handed thread, plug in 220V cable at the tail



Attention :

- If you don't understand something when you use it, please feel free to contact distributors or call our service hotline.
- This product is 220V power supply, mistakenly touching will lead to personally safety and other
- Accidentally injuries and property losses.
- Please install the product where children cannot touch it, and cooperate with professional electrician for installation job.
- For your personal safety, please do not disassemble this product by yourself.
- In order to avoid leakage and problem on product, please don't use this product in wet environment.

Product Profile:

1. USB and Type C ports provide 5V*3A charging for devices.
2. German plug-ins provide 220V 10A power supply for equipment.
3. 15W wireless fast charging, fully compatible

Product Characteristics:

- 1.Charging instruction: wireless charging red light indication(green light on when not charged)
- 2.Power-on protection: long press 5 seconds to turn on the power till the green light is on, then can touch the lifting action lightly, effectively prevent mistakenly touching.
- 3.Intelligent anti-clip: in the process of lifting, the system stops automatically when it encounters abnormal obstacles. And it will stop automatically, then run backward for a long distance, effective anti-pinch and guarantee the product moving system not broken.
- 4.Hidden Design: When it is not using, it is better to keep it close.

Buletooth Speaker:

